

Vuzix Blade Upgraded Quickstart Guide



VR Expert
Demkaweg 11
3555HW, Utrecht

Info@vr-expert.nl
030 7116158



Hardware



In the box

- 1x Vuzix Blade Upgraded
- 1x Vuzix Blade Upgraded case
- 1x Micro USB Power cable (long)
- 1x Micro USB Power cable (short)
- 1x Micro USB extension cable
- 1x Wireless earplugs
- 1x Vuzix Blade Case

Before you start

- The Vuzix Blade Upgraded is **not** water resistance. Do **not** use any sprays. Drips and spills should be avoided.
- Make sure you have Smartphone ready to be paired with the Vuzix blade. This smartphone is necessary to use the device.

How to install

1. Before you start you have to create an account. You can create your Vuzix account here: <https://www.vuzix.com/Account/Register>
2. Install the Vuzix Companion app on your smartphone:
Android:
<https://play.google.com/store/apps/details?id=com.vuzix.companion&hl=en>
IOS:
<https://apps.apple.com/us/app/vuzix-companion/id1383316233>
3. Open the application. You should see a QR code.
4. Turn on the Vuzix Blade Upgraded by pressing/holding the “Power Button” for 3 seconds. You should now see the Home Menu of the Vuzix.
5. From here go to ‘Settings’. Tip: You can swipe to the right.
6. Select ‘Companion Link’ and scan the QR code you have on your mobile.
7. You are now ready to go!

How to connect Wi-Fi

Connect Wi-Fi through the smartphone (recommended)

1. Open the Vuzix app on your smartphone and go to the settings.
2. Select the Wi-Fi under Blade settings.
3. Choose the network you want to connect with and fill in the password.
4. Both your phone and app are now connected to the Wi-Fi.

Connect Wi-Fi through the Vuzix Blade Upgraded

1. Start the Vuzix Blade Upgraded and go to the Settings.
2. Go to Connectivity and choose Wi-Fi, after this choose Add Network.
3. Choose the Wi-Fi network you want to connect with and fill in the password.

How to connect wireless Earplugs

1. Put on the Vuzix Blade Upgraded and turn on the headset.
2. Make sure your Vuzix Blade Upgraded is connected and your Bluetooth is enabled. You can do this by following these steps:
 - a. Go to Settings in the Vuzix Blade Upgraded.
 - b. Select Connectivity.
 - c. Select Bluetooth and turn the Bluetooth on.
3. Select Add Device and choose the device you want to connect with.
4. Swipe up/down with 2 fingers to determine the volume of the Earplugs.

How to download applications

Download applications through smartphone

1. Open the app on the Smartphone.
2. The Vuzix Blade Upgraded should be linked with the smartphone that did the installation of the headset.
3. Log in with your account.
4. Go to the store and you can easily download and install the preferred applications on the Vuzix Blade Upgraded.

Download application through Vuzix website

1. Open the Vuzix Appstore: <https://www.vuzix.com/appstore>
2. Login into your account.
3. Choose any application you would like to download and install on the preferred device.

VR-Expert tips

How to turn on voice recognition

-
-

How to turn on the volume up/down

-
-

How to swipe, tap, etc.

- Two-Finger Tap**
- move backward
 - close action bar
 - close apps



- Two-Finger Hold One Second**
- return to home



- One-Finger Hold One Second**
- open menu, if available



- One-Finger Swipe Up/Down**
- navigate vertical lists



- Two-Finger Swipe Up/Down**
- increase or decrease volume



- Two-Finger Swipe Forward**
- delete action
 - clear current notification
 - delete media
 - add space



- Two-Finger Swipe Backward**
- backspace
 - available gesture definable within app



- Two-Finger Swipe Down Hold One Second**
- mute



- Three-Finger Tap**
- turn the display off and put Blade to sleep



- Three-Finger Hold One Second**
- access virtual assistants on Blade



Contact

If you have more questions or need more information about the Vuzix Blade Upgraded you may reach us.

Email:

sales@vr-expert.nl

support@vr-expert.nl

Call us:

+31 30 71 16 158

Address:

Demkaweg 11
3335 HW, Utrecht
The Netherlands
+31 30 71 16 158

info@vr-expert.nl

Zur Mühle 2 – 4
50226, Frechen
Germany

+49 2234 – 682 953 – 0

info@vrowl.de

